



Wire Guide Arbor
Single Purchase
007-85X04

- Used in wire-guided systems to hold counterweight that balances the batten load.
- Arbor tops and bottoms are fabricated 1/2" (12.6 mm) steel plates with 3/8" (9.5 mm) holes for guide wires located on 15" (381 mm) centers.
- Arbor tops have 7 gauge (4.55 mm) steel plates with holes for lift line terminations and bolt and spacer for the hand line termination. Label on top provides safety information and locations for spreader plates.
- Arbor tops are punched to accept 8 cables.
- Two 3/4" (19 mm) steel arbor rods have three nuts at top and bottom.
- Each rod has a retaining collar with a thumbscrew incorporating an easy-to-grip plastic knob.
- 12 gauge (2.65 mm) steel spreader plate every 2' (0.6 m) (minimum 2).

Ordering Information

Product Code	Length*	Capacity+ 4" (102 mm) Weights	Capacity+ 6" (152 mm) Weights	Wt.
007-85X04	4' 1.22 m	504 229 kg	782 304 kg	34 lbs. 13.6 kg
007-85X05	5' 1.52 m	672 305 kg	1043 473 kg	37 lbs. 16.8 kg
007-85X06	6' 1.8 m	841 381 kg	1303 591 kg	40 lbs. 18.1 kg
007-85X07	7' 2.13 m	1009 458 kg	1564 709 kg	43 lbs. 19.5 kg
007-85X08	8' 2.4 m	1177 534 kg	1825 825 kg	46 lbs. 20.9 kg

*OVERALL LENGTH IS 5 9/16" (141.29 mm) LONGER THAN THE NOMINAL LENGTH.

+AVERAGE CAPACITY USING J.R. CLANCY STEEL COUNTERWEIGHTS.

RWL: RWL is maximum load that can be applied to the arbor which is in "like new" condition and has been properly installed, maintained, and operated.

Dimensions

